



Contents

1.What is RFID.....	2
2.How does it work.....	2
3.RFID Connecting to Cloud Hosted Database (Speedway Connect)	2
Speedway Connect License.....	3
How to Configure Your Server for Speedway Connect.....	3
Setting Speedway Connect to send tags as HTTP Post requests.	13
4.Configuring RFID in RentalPoint.....	16
Setup IMPINJ Fixed Reader	16
Mobile RFID scanner input.....	18
Speedway Settings.....	20
Setup Assets.....	20
RFID Import for Assets	22
RFID for Non Barcoded Items	24
5.Reading Tags from Fixed and/or Mobile Readers.....	27
Stop Read	29
Stop and Load Tags	29
Print / Show Remaining assets.....	31
Checkout	31
Return / Open return	32
6.Custom documents.....	33
7. TroubleShooting PHP Manager Install	34
First download and unpack PHP from the following site:	34
Download and install PHP driver and ODBC driver.....	37
Download and install PHP manager.....	40
Open IIS Manager -> PHP manager.....	42
Configure PHP in PHP Manager	43

1. What is RFID

Radio Frequency Identification is a method of tracking equipment leaving and returning to the warehouse, without the need to physically scan in and out each item. RentalPoint offers both direct (for in house software) and cloud connect (for cloud hosted RentalPoint) options for RFID scanning.

2. How does it work

Each item of equipment is barcode scanned and fixed with an RFID tag. When equipment is wheeled through the scanners (upon leaving or returning to the warehouse), all the tags are scanned and registered in RentalPoint.

The quality of tags, where and how they are placed is vitally important in order to achieve a 100% read rate. The right equipment, the right tags, the right software and the right expertise to put it all together is vital!

RFID tags can be hidden and painted over to remain discreet. For musical instruments, tags can be attached inside and/or under a small black patch.

 RFID is an additional module to RentalPoint and is priced as such. You still need to bar code all assets, barcoding and RFID go hand in hand. We are also working on a mobile RFID solution, so that gear can be tracked before leaving the job site. If you're interested in further information on RFID then please email sales@rentp.com

3. RFID Connecting to Cloud Hosted Database (Speedway Connect)

Installing the Speedway connect software on the reader allows the reader to be configured to send tags over the internet to a web server. Use this set up for fixed readers where the RentalPoint database is not on the same network/VPN as the reader.

A local computer running RentalPoint is not required in this case. RentalPoint can reside on a cloud or other server not local to the reader's network.

 ***Once Speedway Connect is installed on the reader you will no longer be able to directly connect to it using the RentalPoint RFID window as it overrides all direct connections. Uninstall Speedway Connect if you wish to connect to it directly again***

To use Speedway Connect you'll need:

1. Web server with connection to SQL server database and port open to the internet that the reader can send requests to.
2. Install speedway connect on the reader (note this will prevent RFID scan window from connecting to it directly).
3. Get a speedway connect license from a dealer (dealer should also have advice on which settings to use for the situation as these are then set in speedway connect instead of RP)
4. Point speedway connect to the PHP file on the web server
5. Set up RentalPoint reader list to have readers get results from speedway connect

Speedway Connect License

For testing purposes, Speedway Connect will allow a maximum of 500 tags per session. A license key can be obtained from a licenced vendor. <http://go.impinj.com/contact-sales>

<https://support.impinj.com/hc/en-us/articles/202755278-Speedway-Connect>

How to Configure Your Server for Speedway Connect

First you'll need to do some work on your server. This involves downloading and installing some required files, then configuring the server roles and IIS.

Download and Install Required Files

Navigate to <http://www.microsoft.com/web/downloads/platform.aspx>. Click **Free Download** and follow the on screen instructions to launch the MS Web Platform. Microsoft provides this free tool to help you find the files you need and install them easily.

Microsoft Web Platform Installer 5.0

The Microsoft Web Platform Installer (Web PI) is a free tool that makes getting the latest components of the Microsoft Web Platform, including Internet Information Services (IIS), SQL Server Express, .NET Framework and Visual Web Developer easy. The Web PI also makes it easy to install and run the most popular free web applications for blogging, content management and more with the built-in [Windows Web Application Gallery](#).

Why you'll love it.

- It's Free**
The Web PI is a free download with no strings attached. We don't know about you, but we definitely like free.
- It's Tiny**
Weighing in at under 2 megabytes, the Web PI is the fastest way to get the components that make up the Microsoft Web Platform.
- It's Smart**
Installing Web Apps or updating the Microsoft Web Platform, Web PI's improved validation support ensures everything just works.
- It's Up-To-Date**
Whether you're updating or installing components, Web PI always includes the latest version of the Microsoft Web Platform.
- It's Cultural**
Available in 14 different languages. Choose your language and if a component is available in that language, Web PI will ensure you get it.
- It's App-tastic**
Popular, free and ready to install Web Apps including Umbraco, WordPress, Acquia Drupal, SugarCRM, and more!

By downloading and using the Web Platform Installer (WebPI), you agree to the [license terms](#) and [privacy statement](#) for WebPI. This installer will contact Microsoft over the Internet to retrieve product information. WebPI uses the Microsoft Customer Experience Improvement Program (CEIP), which is turned on by default, see [privacy statement](#) for more information. Some of the Microsoft software obtained through WebPI may use CEIP. To view which software uses CEIP, see [here](#).


Free Download

[View System Requirements and File Details](#)

Using the MS Web Platform, search for the following files. Click **Add** to put them in your cart.

- Microsoft Drivers 3.2 for PHP v5.6
- PHP 5.6.0 For IIS Express
- Microsoft Visual C++ 2012 Redistributable Package
- PHP Manager for IIS

Once you've added all the required files click **Install**. You should see a screen similar to the one below. Click **I Accept** to install the selected items. After all items have successfully installed, reboot your server.




NOTE: if you PHP Manager for IIS fails to install, see trouble shooting at the end of the document.

Configure Web Server IIS Roles

- Open **Server Manager**, expand **Roles** (you may need to wait a few moments while the list populates) and click on **Web Server (IIS)**.
- Scroll down to the **Role Services** area and ensure that the following services are installed.
 - Static Content
 - Default Document
 - CGI
 - ODBC Logging
 - Basic Authentication
 - Windows Authentication
 - IIS Management Console

If a service is *Not Installed*, simply click **Add Role Services**, tick the boxes on the items you want to install and click **Next**. Follow the on screen instructions.

After you've completed this step, restart your server.



Server Manager (RP-DEVSERVER)



Roles

View the health of the roles installed on your server and add or remove roles and features.


Role Services: 24 installed

Role Service	Status
Web Server	Installed
Common HTTP Features	Installed
Static Content	Installed
Default Document	Installed
Directory Browsing	Installed
HTTP Errors	Installed
HTTP Redirection	Not installed
WebDAV Publishing	Not installed
Application Development	Installed
ASP.NET	Not installed
.NET Extensibility	Not installed
ASP	Not installed
CGI	Installed
ISAPI Extensions	Not installed
ISAPI Filters	Not installed
Server Side Includes	Not installed
Health and Diagnostics	Installed
HTTP Logging	Installed
Logging Tools	Installed
Request Monitor	Installed
Tracing	Not installed
Custom Logging	Not installed
ODBC Logging	Installed
Security	Installed
Basic Authentication	Installed
Windows Authentication	Installed
Digest Authentication	Not installed
Client Certificate Mapping Authentication	Not installed
IIS Client Certificate Mapping Authentication	Not installed
URL Authorization	Not installed
Request Filtering	Installed
IP and Domain Restrictions	Not installed
Performance	Installed
Static Content Compression	Installed
Dynamic Content Compression	Not installed
Management Tools	Installed
IIS Management Console	Installed
IIS Management Scripts and Tools	Not installed

OR




Server Roles Continued:




Configure IIS CGI Handler Mappings


- In the Windows Start Menu type **run** and hit enter.
- Then type **inetmgr** and hit enter. This will launch the **Internet Information Services (IIS) Manager**.
- In the IIS Manager locate your server name in the left hand **Connections** pane and click it.
- The right pane will refresh with the available features for your sever. Locate the **Handler Mappings** feature and double click to launch it.



- In the **Handler Mapping** list, search for **PHP_via_FastCGI**. (Don't worry if it doesn't exist, we've included instructions on how to add it.)



- If the **PHP_via_FastCGI** module mapping doesn't exist, navigate to the **Actions** pane on the right hand side
- click **Add Module Mapping...** and enter the following information.
 - The default PHP folder is located in C:\Program Files (x86)\iis express\PHP\v5.6, however this may differ from your installation.
 - You can use any version of PHP - provided that you select the appropriate path and executable.
 - Click **OK** to save your changes.



Add Module Mapping

Request path:
*.php
Example: *.bas, wsvc.axd

Module:
FastCgiModule

Executable (optional):
"C:\Program Files (x86)\iis express\PHP\v5.6\php-cgi.exe"


Name:
PHP_via_FastCGI

Request Restrictions...

OK Cancel

There's **one final step** that you need to complete (regardless if you added the mapping yourself, or the mapping was already in the list).


- Double click to open the **PHP_via_FastCGI** mapping.
- Click **Request Restrictions** and configure the Mapping as follows:




Click **OK** on all dialogs to save the configuration.

Create a Secure Database User


- In SQL Management Studio create a special database user for RFID (ie. RPRFID).
- Configure the user with SQL Server authentication, give the user a password and select **Enforce Password Policy**.
- Ensure that you set your Default Database and Default Language accordingly.



This user only has the public role assigned.



This user is only mapped to your RP database. Click OK to save your new user.



- Use the following SQL script to grant the required permissions to this user.
- Ensure that you enter the appropriate USERNAME and DATABASE values (highlighted).

```

DECLARE @USERNAME VARCHAR(50);
DECLARE @DATABASE VARCHAR(50);
SET @USERNAME = 'UserName';
SET @DATABASE = 'DatabaseName';
DECLARE @SQLText nvarchar(MAX);
SET @SQLText = '
USE {DATABASE}
GRANT CONNECT TO {USERNAME}

```

```

GRANT SELECT ON [dbo].[tblRFIDEvents] TO {USERNAME}
GRANT INSERT ON [dbo].[tblRFIDEvents] TO {USERNAME}
GRANT UPDATE ON [dbo].[tblRFIDEvents] TO {USERNAME}
GRANT DELETE ON [dbo].[tblRFIDEvents] TO {USERNAME}
;

```

```

SET @SQLText = REPLACE (@SQLText, '{USERNAME}', @USERNAME)
SET @SQLText = REPLACE (@SQLText, '{DATABASE}', @DATABASE)
EXECUTE (@SQLText)

```

- The RFID server files can be found in the rentalpoint ..\sys\RFIDScan\RFIDServer folder after installing RFID Setup from <http://www.rentp.com/updates/login.php>.
- Save the files in RFIDServer to a folder on your web server. (i.e. C:\inetpub\wwwroot)

- The path to the **RFID.php** file will need to be added to the **URL** box in the Speedway connect settings as below.
 - Ex. <http://159.999.333.111:928/RFIDWeb/RFID.php>

Outside Connection

After completing the steps above to allow the reader to connect from outside your local network, you may have to allow IIS through a port in the firewall and forward it to the internal IP address of the Server machine. Once configured you should be able to connect to [http://\[Your server IP or Web site address\]/RFIDWeb/test.php](http://[Your server IP or Web site address]/RFIDWeb/test.php) and see the message below

Server Name: DEVSRV\SQLEXPRESS

Database Name: devdb

Test Connection: Connection established.

Test Access rights: passed


Test INSERT right: passed

Test SELECT right: passed.


Test Delete right: passed

Connect to the database

Find and edit the **config.php** file in the **RFIDWeb** folder.



Change the Server, Database, user name and password to the SQL Server and a user set up on the server with SQL Authentication and save.




Installing Speedway Connect

Note: Once Speedway Connect is installed on the reader you will no longer be able to directly connect to it using the RentalPoint RFID window as it overrides all direct connections. Uninstall Speedway Connect if you wish to connect to it directly again

Follow the directions in the link below to install Speedway connect to the reader and update the Octane firmware.

<https://support.impinj.com/hc/en-us/articles/360004070340-Installing-Upgrading-Speedway-Connect>



The screenshot shows a web browser window with the URL `speedwayr-11-fb-2d.local/cgi-bin/index.cgi`. The page displays several sections:

- READER**

Reader Name	SpeedwayR-11-FB-2D
Uptime	0 Days, 0 hours, 0 minutes, 43 seconds
System Time	Fri Sep 13 20:26:45 UTC 2019
LLRP Status	Connected: ::ffff:127.0.0.1
RFID Status	Active
- DETAILS**

Model Name	Speedway R420
Regulatory Region	FCC Part 15.247
MAC Address	00:16:25:11:FB:2D
Software Version	5.12.2.240 (Build cbc9ad1d0d1)
Hardware Version	250-005-013
Application SW Version	2.0.6.0
Serial Number	370-16-51-0290
- NETWORK**

IP Address	2607:fea8:6040:b90::4
Network Mask	
Default Route	fe80::6a8f:2eff:fec8:3402
Broadcast Address	
- READER UPGRADE**

Upgrade Status	Ready
Last Operation Status	N/A
Select Upgrade File	<input type="button" value="Browse..."/> No file selected.
Upgrade Now	Upgrade [↑]
- ANTENNA HUB**

Feature Status	Disabled
Press to Enable	Enable Antenna Hub
- READER REBOOT**

Reboot Status	Ready To Reboot
Press to Reboot	Reboot
- QUICK LINKS**
 - www.impinj.com
 - support.impinj.com
 - [Speedway Documentation](#)
 - [Third Party Software Licenses](#)
 - [End User's License Agreement](#)

Setting Speedway Connect to send tags as HTTP Post requests.

Open the Speedway connect interface by entering the following in a browser, where AA-AA-AA is the last 6 characters of the reader's MAC address (this can be found on a sticker on the reader).

`https://speedway-AA-AA-AA.local`

ex.

`https://speedway-11-fb-2d.local,`

Under the output connection check the 'HTTP POST' option. Enter the same reader name as the 'Configuration description' in Rentalpoint set up (barcoding #2). This value can be anything unique to the reader.

Output : Connection

Serial Port:

Baud Rate: 115,200

Keyboard Emulation:

USB Flash Drive:

TCP/IP Socket:

Port: 14150 (1 - 65535 number)

HTTP POST:

Reader Name: Impinj RFID Reader

URL: http.com/Jaclyn/RFID.php

Update Interval: 5 (0 - 86400 secs)

RP Setup Rf

Select Configuration	Configuration description
Configuration	Impinj RFID Reader
Impinj RFID Reader	Reader Types allowed
MOBILE	<input type="radio"/> Fixed Reader

Under **Output : Data**

If the Speedway connect version has the **Format** option set this to **Key-Values Pairs**

Output : Data

Format: JSON
Delimiter: Key-Value Pairs

Set the delimiter to **Comma** and Line Ending to **LF**

Output : Data

Delimiter: Comma
Line Ending: LF

Antenna Port:

Timestamp:

Peak RSSI: The Reader Tag Data Output Settings

TID:

Start: (0 - 65535 bit)

Length: (1 - 32 words)

User Memory:


Start: (0 - 65535 bit)

Click **Apply** to add the settings. Ensure the Status at the top shows a green tag before clicking apply to start the reader.

See 'Configure RFID in RentalPoint' below for Speedway settings.


4. Configuring RFID in RentalPoint

RFID mode is enabled in parameter setup, barcoding parameter #2 (Barcode Scanning + RFID).



Setup IMPINJ Fixed Reader

To set-up a fixed IMPINJ Reader go to setup parameter #2, select Barcode Scanning + RFID after which the setup window will appear.



Click **New** then enter a unique name for the **Configuration description**. For the fixed reader select **Fixed Reader** for the type, then enter the IP or host name for the **Fixed Reader Host**.



RFID in RentalPoint

The **Min. RSSI** setting can be used to exclude low signal tags from the reader so that for instance tags sitting on a shelf to one side of the portal are excluded.

Tag Format can be defined if all your tags follow a certain format so that any non matching tags will be excluded from the read. For instance tags with 18 leading zeros and 6 digits (“0000000000000000000888776”) would get a tag format of “000000000000000000”. X in a position will allow any character.

To test the reader select a row and click ‘Open’ to launch the setup version of the reader app.

Here the settings entered can be tested against the reader.


The screenshot shows the 'Reader Setup' application window with the following configuration details:

- Reader name:** Inout portal
- Reader connection:** 192.168.0.25
- Configuration:** Impinj Default
- Save Config
- Minutes before closing idle reader (no new tags):** 5
- Min. RSSI:** -70
- Test Beep:** Console Beep (selected), Frequency (200 - 9000): 3000
- Windows Beep
- .wav file beep
- Tag Format (only include tags with the initial format (X for ignore)):** (empty field)
- Database Connection String (leave blank to read from RP registry):** (empty field)
-
- Messages:** (empty text area)
-

At the bottom of the window, the status bar shows: "Excluding tags with RSSI below : -70" and "Tag Format : Any".

Speedway Settings

For fixed readers configurations (only or both), check the **Use Speedway Connect** option. If you have an earlier version that does not have this option, enter **swc** in the **Fixed Reader Host** box.



Setup Assets

A barcode number needs to be assigned to all assets whether the actual barcode appears on the item or not, though having the barcode on the product can be helpful for sight identification and lookup.

Assets with an RFID tag will have the tag stored in the RFID Tag field in asset properties. All tags must be longer than 15 characters to be identified as such by RentalPoint.

RP Edit Asset Record ✕

General Service Information Financial Details Notes

Barcode

Description

Model Number

Stock Number

Serial Number

Vendor 

PO number 

Bin Location

Quantity



Location

RFID Tag

(Note: RFID tags should be longer than 15 characters)

RFID Import for Assets

RFID Tags can be imported using the product or asset import from csv files.



Select the .csv file that has a list of barcodes with the corresponding RFID Tag. These should be the first and second column in the spreadsheet.

Ensure the column order on the window matches the order in the spreadsheet, then click 'Import'

RFID Import


This import will update RFID tag when given an existing barcode. For new assets please use the 'Rental product' or 'Asset' import options.

Any barcodes not found will be added to a separate .csv sheet that can be used to import new assets.

.csv File example

Asset Barcode	RFID Tag
100009	R1000000000000000000000000000045
100011	R1000000000000000000000000000046


Field 1: Asset Barcode Field 2: RFID Tag

RFID for Non Barcoded Items

While non-barcoded items do not have separate asset records for each item, they can still be tagged and read with the RFID reader. Unlike a 'non-tracked barcode' however, where the barcode is assigned at the product level and scanned for each individual checkout of that product, the RFID tag for each non-tracked item must be unique. With RFID, since the reader is contently reading the tags in its view, it needs the unique tag to determine that there are two or more separate items.

In product properties (via Inventory Setup (F10)), products that are not checked as 'Barcode Track' will have an extra tab called 'Barcodes\RFID tags'.



The screenshot shows the 'EDIT PRODUCT RECORD : CABLES' form. The 'Barcode\RFID tags' tab is highlighted with a red box. The 'Barcode Track' checkbox is also highlighted with a red box. The form contains the following fields and options:

- Product Code: CABLES
- Description: Cables
- Model No.:
- Colour:
- Part Number:
- Qty Owned: 603.00 (All Locations)
- Country of Origin:
- Revenue Code:
- Default Accessory Discount:
- Non-tracked Barcode: CAB1
- Product Options: For Individual Rental / Sale
- Barcode Track: (highlighted with a red box)
- Don't allow product to be discounted:
- Expand When Added to a Booking:
- Auto Checkout this Item:
- Warehouse active:
- When Cross rented, the cost is freight:

Reader: 3190

Start Reading Tags | Reader Responses

Clear Remove Selected Manage Excluded DEMO MODE

Booking : ABCC000100001
Show : West Spring Convention

of Items on Booking: 4

of RFID Tags: 4 | RFID Tags Read: 2 | Remaining RFID: 2

Stop Read

Stop and Load Tags

Print Additional and Missing

Legend

- Tag not on booking
- Tag from different location
- Tag on booking, no warnings

#	Barcode	RFID	Description	Show	Booking
1	PM7886	000000000000000000999495	Powered Monitor Speaker	West Spring Convention	ABCC000100001
2	AM1000	000000000000000000999555	Audio Mixer 9928-988	West Spring Convention	ABCC000100001

Mobile reader input

The cursor needs to be placed in the mobile reader input box in order for the tags to be processed. If focus is lost, a warning beep will sound and the box will be displayed in red.

Mobile reader input


Click the red X next to the box if you wish to stop accepting tags from the reader temporarily. Click the green check mark to start accepting tags from the reader again.

If both fixed and mobile readers are in use, the steps for the fixed reader will be followed at first then the mobile reader input will become available after the initialization period is complete.


Print / Show Remaining assets

Checkout

Two buttons above the 'Equipment to be barcode scanned' grid will allow the grid to be printed or viewed in a pop-up window to view more equipment and could be placed on a secondary monitor.



The pop up window displays the type of the product (barcoded only or RFID tagged) in the far left of the grid. Items can be filtered to show a certain group and/or barcoded or RFID only.



Type	Product Code	Description	Qty	Qty Scanned This Session	Group
RFID	MIC2	mic2	3	0	SOUND EQUIPMENT
RFID	CHAIR	Blue Chairs	2	0	Furniture
RFID	RTABLE	tables - round	2	0	Furniture
RFID	RC	Road case	1	0	Road cases
RFID	TEMPS	Temporary Shed	1	0	Sheds
RFID	MON	Monitor 25"	10	0	Video Equipment


Display: All Asset Tracked Barcode Only RFID Only

Group: All

Print

The print feature will print the unscanned assets with a separate group on each page. It can also be sent to csv and saved. Printing the report from the grid will allow the filter to be applied to the report.

The report will page break for each product group so the pages can be handed off to the department responsible for that equipment type.



6. Custom documents

An insert field for custom rtf documents is available to show the equipment that has only a barcode and ones that have rfid tags.


&RFIDBCC : 2 &

The field will work with booking hardcopy/pull sheet/pick list documents as well as packing lists, collection dockets and return receipts.

Products that have rfid tags on all assets (booking hardcopy documents) will display **RF** in the field while products that have barcodes only or do not yet have rfid tags on all assets will show **BC**. Non-tracked equipment will show a blank space in the fields.


7. TroubleShooting PHP Manager Install

1. PHP Manager for IIS failed to install



First download and unpack PHP from the following site:

Download and unpack PHP: <https://www.php.net/downloads.php>



← → ↻ windows.php.net/download#php-7.3

PECL For Windows

[PECL extensions](#) for Windows is being worked on. Windows DLL can be downloaded right from the [PECL website](#).

The PECL extension [release](#) and [snapshot](#) build directories are browsable directly.

Which version do I choose?

IIS
If you are using PHP as FastCGI with IIS you should use the Non-Thread Safe (NTS) versions of PHP.

Apache
Please use the Apache builds provided by [Apache Lounge](#). They provide VC14, VC15 and VS16 builds of Apache for x86 and x64. We use their binaries to build the Apache SAPIs.

With Apache you have to use the Thread Safe (TS) versions of PHP.

VC14, VC15 & VS16
More recent versions of PHP are built with VC14, VC15 or VS16 (Visual Studio 2015, 2017 or 2019 compiler respectively) and include improvements in performance and stability.

- The VC14, VC15 and VS16 builds require to have the *Visual C++ Redistributable for Visual Studio 2015-2019 x64* or *x86* installed

PHP 7.3 (7.3.8)

[Download source code](#) [26.89MB]
[Download tests package \(phpt\)](#) [14.17MB]



VC15 x64 Non Thread Safe (2019-Jul-30 16:05:44)

- Zip** [24.4MB]
sha256: 19898b2c0f60e022a9567b6ff916e20881ac8907051f116915a55bc419ae64be
- [Debug Pack](#) [22.99MB]
sha256: de29e42a9605b4f8935cb1d76fdbbc90850847f7f601bb1cbdf9fd24ed08bac1
- [Development package \(SDK to develop PHP extensions\)](#) [1.24MB]
sha256: 19428bcd80cd98f4bc03d57ad7d584aed6bd28d37eb97662bbe0a96f82612fc

VC15 x64 Thread Safe (2019-Jul-30 16:05:58)

- [Zip](#) [24.53MB]
sha256: 9b9339010e88bbf4b0945cc196ed4679971462695bc622ab097e1bc0ee117fba
- [Debug Pack](#) [23.09MB]
sha256: 6b76a912bd5296386331cdb1d7014753fc2fc08b486e5b09c7a2a9bc691e9fdb
- [Development package \(SDK to develop PHP extensions\)](#) [1.25MB]
sha256: 71832cd52bee6f1ca67ac548216b3cfff6cd3c355982a84d7d36862933fd8389

Extract the zip to **C:\bin\php**




Download and install PHP driver and ODBC driver

<https://docs.microsoft.com/en-us/sql/connect/php/system-requirements-for-the-php-sql-driver?view=sql-server-2017>

1. Download PHP driver 5.6 (or higher)

System Requirements for the Microsoft PHP for SQL Server

02/10/2019 • 8 minutes to read •  +3



This document lists the components that must be installed on your system to access data in a SQL Server using the Microsoft Drivers for PHP for SQL Server.

Versions 3.1 and later of the Microsoft PHP Drivers for SQL Server are officially supported. For full requirements including earlier versions of the PHP drivers, see the [support matrix](#).

PHP

For information about how to download and install the latest stable PHP binaries, see [the PHP website](#). PHP binaries for SQL Server require the following versions of PHP:

PHP for SQL Server driver version →

↓ PHP version

5.6

5.3

5.2

4.3

4

Download the Microsoft SQL Server


02/10/2019 • 2 minutes to read • 

 [Download PHP Driver](#)

Windows

The following versions of the drivers for PHP on Windows are available:

- Microsoft Drivers 5.6 for PHP for SQL Server
- Microsoft Drivers 5.3 for PHP for SQL Server
- Microsoft Drivers 5.2 for PHP for SQL Server
- Microsoft Drivers 4.3 for PHP for SQL Server
- Microsoft Drivers 4.0, 3.2, 3.1, and 3.0 for PHP for SQL Server



Extract and install to **C:\bin\php\ext**

PHP

For information about how to download and install the latest stable PHP binaries, see [the PHP web site](#). The Microsoft Drivers for PHP for SQL Server require the following versions of PHP:

PHP for SQL Server driver version → ↓ PHP version	5.6	5.3	5.2	4.3	4.0	3.2	3.1
7.3	7.3.0+						
7.2	7.2+ ¹	7.2+ ¹	7.2+ ¹				
7.1	7.1.0+	7.1.0+	7.1.0+	7.1.0+			
7.0		7.0.0+	7.0.0+	7.0.0+	7.0.0+		
5.6						5.6.4+	
5.5	If you installed PHP 7.3, you can use only version 5.6					5.5.16+	5.5.16+
5.4						5.4.32	5.4.32

SQL Server

Azure SQL Databases are supported. For information, see [Connecting to Microsoft Azure SQL Database](#).

PHP for SQL Server driver version → ↓ SQL Server version	5.6	5.3	5.2	4.3	4.0	3.2	3.1
Azure SQL Database	Y	Y	Y	Y			
Azure SQL Managed Instance	Y	Y	Y	Y			
Azure SQL Data Warehouse	Y	Y	Y	Y			
SQL Server 2017	Y	Y	Y	Y			
SQL Server 2016	Y	Y	Y	Y	Y		
SQL Server 2014	Y	Y	Y	Y	Y	Y	Y
SQL Server 2012	Y	Y	Y	Y	Y	Y	Y
SQL Server 2008 R2	Y	Y	Y	Y	Y	Y	Y
SQL Server 2008	If you choose 5.6 version, you can use only SQL Server 2008 R2 and higher				Y	Y	Y

2. On the same page download the ODBC Driver

ODBC Driver

The correct version of the Microsoft ODBC Driver for SQL Server is required on the computer on which PHP is running. You can download all supported versions of the driver for supported platforms or [this page](#).  [Download ODBC here](#)

If you are downloading the Windows version of the driver on a 64-bit version of Windows, the ODBC 64-bit installer installs both 32-bit and 64-bit ODBC drivers. If you use a 32-bit version of Windows, use the ODBC x86 installer. On non-Windows platforms, only 64-bit versions of the driver are available.

PHP for SQL Server driver version → ↓ ODBC Driver version	5.6	5.3	5.2	4.3	4.0	3.2	3.1
ODBC Driver 17+	Y	Y	Y				
ODBC Driver 13.1	Y	Y	Y	Y	Y		
ODBC Driver 13					Y		
ODBC Driver 11	Y	Y	Y	Y	Y	Y	Y

If you are using the SQLSRV driver, [sqlsrv_client_info](#) returns information about which version of SQL Server Microsoft ODBC Driver for SQL Server is being used by the Microsoft Drivers for PHP for SQL Server. If you are using the PDO_SQLSRV driver, you can use [PDO::getAttribute](#) to discover the version.

Download ODBC Driver for SQL Server

2018-03-12 • 2 minutes to read •  +1

Microsoft ODBC Driver 17 for SQL Server

Windows

- [Download the Microsoft ODBC Driver 17 for SQL Server on Windows](#)

Linux and macOS

Download and install PHP manager

<https://github.com/edgardo001/PHPManagerForIIS-Versions>

Dismiss

Join GitHub today

GitHub is home to over 40 million developers working together to host and review code, manage projects, and build software together.

[Sign up](#)

PHPManagerForIIS-1.2.0-x64 - IIS 7.msi

5 commits 1 branch 0 releases 1 contributor

Branch: master [New pull request](#) [Find File](#) [Clone or download](#)


edgar001 Update README.md Latest commit b42923a on Jul 31, 2018

PHPManagerForIIS-1.2.0-x64 - IIS 7.msi	first commit	2 years ago
PHPManagerForIIS-1.2.0-x86 - IIS 7.msi	first commit	2 years ago
PHPManagerForIIS-1.3.0-x64 - IIS 8.msi	first commit	2 years ago
PHPManagerForIIS-1.4.0-x64 - IIS 10.msi	first commit	2 years ago
README.md	Update README.md	last year

 [PHPManagerForIIS-1.2.0-x64 - IIS 7.msi](#)

Double click the downloaded file to install

Open IIS Manager -> PHP manager



Configure PHP in PHP Manager

Internet Information Services (IIS) Manager

WIN-B58FV720PM7 > Sites > Default Web Site

File View Help

Connections

- Start Page
- WIN-B58FV720PM7 (WIN-B58FV)
 - Application Pools
 - Sites
 - Default Web Site

PHP Manager

Use this feature to check the PHP runtime settings, to configure PHP runtime directives and to enable

PHP Setup

PHP version: 7.3.8

PHP executable: C:\bin\php\php-cgi.exe

Handler mapping: [Local](#)

[Register new PHP version](#) | [Change PHP version](#) | [Check phpinfo\(\)](#)

PHP Settings

Configuration file: [C:\bin\php\php.ini](#)

Error log: [C:\Windows\Temp\php-7.3.8_errors.log](#)

[Configure error reporting](#) | [Set runtime limits](#) | [Manage all settings](#)

PHP Manager

Use this feature to check the PHP runtime settings, to configure PHP runtime directives and to enable or disable PHP

PHP Setup

Not optimal PHP configuration detected on this machine. [View recommendations.](#)

PHP version: 5.6.31

PHP executable: C:\Program Files (x86)\PHP\v5.6\php-cgi.exe

Handler mapping: [Local](#)

[Register new PHP version](#) | [Change PHP version](#) | [Check phpinfo\(\)](#)

